

ACONATIC

คู่มือการใช้งาน

AN-8000BT



รายการอุปกรณ์ :

1 x ลำโพงบลูทูธ


1 x สายชาร์จ Micro USB

1 x สาย AUX 3.5 mm

1 x คู่มือการใช้งาน

วิธีการชาร์จ

1. เปิดฝาครอบ USB ออก
2. นำปลายสายชาร์จ Micro USB ต่อเข้ากับช่อง Micro USB ที่อยู่ด้านหลังของลำโพง
3. เชื่อมต่อปลายสาย Micro USB อีกด้านเข้ากับพอร์ต์ USB ของคอมพิวเตอร์หรืออะแดปเตอร์ AC (ไม่รวมอยู่ในเครื่อง)






**Micro USB
Charging Port**

**Micro USB
Charging Port**

**Micro USB
Charging Cable**

Computer



ด้านหน้า

1. ไมโครโฟน

ด้านบน:

2. 

กดปุ่ม Power ค้าง  เพื่อทำการเปิดเครื่อง

3. ไฟแสดงสถานะ

4. ปุ่ม 

กดค้างเพื่อลดระดับเสียง
กด 1 ครั้ง เพื่อข้ามไปยัง
แทร็กก่อนหน้า

5. ปุ่ม 

หยุดเล่น / เล่น
กด 1 ครั้ง เพื่อรับสาย
กด 1 ครั้ง เพื่อวางสาย
กด 2 ครั้ง เพื่อโทรกลับ

6. ปุ่ม 

กดค้างเพื่อเพิ่มระดับเสียง
กด 1 ครั้ง เพื่อข้ามไปยังแทร็กถัดไป


7. ช่องชาร์จ Micro USB

8. ช่องเสียบสาย Aux


9. ฝาครอบกันน้ำ

ตำแหน่งการควบคุม


FRONT




TOP



BACK



BACK



ข้อมูลจำเพาะของแบตเตอรี่:

แบตเตอรี่ลิเธียม: 3.7V

ความจุของแบตเตอรี่: 2000 mAh Li-polymer battery

ระยะเวลาในการเล่น: ประมาณ 13-15 ชั่วโมง

เวลาในการชาร์จ : 4-5 ชั่วโมง

วิธีการใช้งาน

เพื่อการเพลิดเพลินกับการเล่นเพลง บนลำโพงของคุณ ตรวจสอบให้แน่ใจว่าคุณเชื่อมต่อกับอุปกรณ์บลูทูธแล้ว เมื่อเชื่อมต่อแล้วให้กด PLAY บนอุปกรณ์บลูทูธ ของคุณหลังจากเริ่มเล่นแล้วคุณสามารถควบคุมเพลงด้วยอุปกรณ์ที่เชื่อมต่อ

การใช้สาย Aux-in

สำหรับอุปกรณ์เครื่องเล่นเพลงที่รองรับ หรือเครื่องเล่น Mp3 / Mp4 โปรดใช้สายที่นำมาเพื่อเชื่อมต่อของอุปกรณ์ภายนอกของคุณเข้ากับช่อง “Aux-in” ของเครื่องนี้ ในขณะที่ใช้อุปกรณ์ภายนอกฟังก์ชันทั้งหมดจะถูกควบคุมโดยอุปกรณ์ ยกเว้นสำหรับปุ่มเล่น / หยุดชั่วคราว

****** ลำโพงไม่สามารถกันน้ำได้เมื่อใช้ฟังก์ชัน AUX และชาร์จแบตเตอรี่ใหม่ขณะที่ฝาเปิดอยู่

การจับคู่ & เชื่อมต่อกับอุปกรณ์

1. กดปุ่ม  เพื่อเปิดอุปกรณ์ จากนั้นเสียงจะดังขึ้นและไฟแสดงสถานะ LED จะเริ่มกะพริบเป็นสีฟ้าอย่างรวดเร็ว
2. ระหว่างกระบวนการจับคู่ ลำโพงและอุปกรณ์ที่ใช้ ให้ห่างจากกันไม่เกิน 3 ฟุต
3. เปิดเมนูการตั้งค่าบลูทูธ บนอุปกรณ์ที่ต้องการเชื่อมต่อ จากนั้นตั้งค่าอุปกรณ์ เพื่อค้นหา
4. เมื่ออุปกรณ์ที่ต้องการเชื่อมต่อ ให้อ่านหาลำโพง “AN-8000BT” จากรายการอุปกรณ์ที่พบ
5. อุปกรณ์ที่ต้องการเชื่อมต่อ บางตัวต้องใช้รหัสผ่านในการเชื่อมต่อหากจำเป็นต้องป้อนรหัสผ่าน “0000” จากนั้นเลือก ตกลง หรือ ใช่ เพื่อจับคู่ลำโพงกับอุปกรณ์ของคุณ
6. หลังจากการจับคู่สำเร็จไฟแสดงสถานะ LED จะกะพริบซ้ำ ๆ

หมายเหตุ: หากคุณต้องการเชื่อมต่อลำโพงกับอุปกรณ์อื่น คุณจะต้องยกเลิกการจับคู่ลำโพงจากอุปกรณ์ที่จับคู่ในปัจจุบันก่อน โดยให้เลือก AN-8000BT จากนั้นเลือก “เลิกจับคู่” หรือ “ลืมอุปกรณ์”

บลูทูธ:

เวอร์ชันบลูทูธ: 5

ระยะเวลาใช้งาน: 10 เมตร

ข้อมูลจำเพาะ

- กำลังขับ: 5W*2
- ขนาดลำโพง: 2.75 นิ้ว *2
- การตอบสนองความถี่: 100Hz-20KHz
- สัญญาณต่อเสียงรบกวน: ≥80dB
- ขนาดผลิตภัณฑ์: กว้าง 282 X ยาว 75 X สูง 106 mm
- ความจุของแบตเตอรี่: 2000mAh Li-polymer battery
- มีช่อง Aux, Bluetooth
- อุปกรณ์: สาย 3.5mm, สายชาร์จ Micro USB, คู่มือการใช้งาน

คำเตือนและขอควรระวัง

ก่อนที่จะใช้ลำโพง ตรวจสอบให้แน่ใจว่าซัลโฟนาไมด์ช่องเสียบ Micro USB ที่ด้านหลังของลำโพง ปิดสนิทหากน้ำเข้าสู่ลำโพงอาจชำรุดเสียหายได้

1. ลำโพงนี้ผ่านการทดสอบจาก IP67 และผ่านการรับรองว่ากันน้ำได้ไม่เกิน 30 นาที ในระดับน้ำไม่เกิน 1 เมตร ในขณะที่การป้องกันฝุ่นโดยรวมช่วยป้องกันทรายสิ่งสกปรกและอื่น ๆ
2. หากลำโพงเปียกขออนุญาตให้ลำโพงแห้งสนิทก่อนที่จะใช้อีกครั้ง
3. ขณะที่ลำโพงมีปลอกซิลิโคนเพื่อการป้องกัน แต่ลำโพงสามารถชำรุดได้ เมื่อตกจากที่สูง
4. ไม่รับประกันการความเสียหายที่เกิดจากผู้ใช้งาน

ACONATIC

Instruction Manual

AN-8000BT




Package includes :

- 1 Bluetooth speaker
- 1 USB to Micro USB cable
- 1 3.5mm aux cable
- 1. Manual

Charging the Speaker:

1. Lift the waterproof USB cover
2. Connect the small end of the Micro USB charging cable to the Micro USB port located on the back of the speaker
3. Connect the larger end of the Micro USB ,charging cable to your computer's USB port or an AC adaptor (not included).



FRONT

1. Microphone

TOP:

2. 

Long Press power  to open the device,

3.. LED indicator light

4. Button 

Long press to decrease the volume

Quick press to skip to the previous track

5. Button: 

PAUSE/PLAY

Quick press to answer as call

Quick press to end an call

Short press two times is the callback

6. Button 

Long press to increase the volume

Quick press to skip to the next track

Back:


7. Micro USB charging port

8. Aux-in jack


9. Waterproof USB cover

Location of Controls


FRONT




TOP



BACK



BACK



Bluetooth information :

Bluetooth specification: 2.1+EDR

Operating distance: 10 meters Class II

Battery information:

Built –in Lithium Battery: 3.7V

Rechargeable: 2000mAh Li-polymer battery

Music playing time: about 13-15 hours

Charging time: 4-5 hours

Playing Music

Playing Music wirelessly

To enjoy wireless music on your Waterproof speaker ,make sure your are connected to a Bluetooth enabled device ,Once connected ,press PLAY on your Bluetooth device ,After playback starts ,you can control the music with your connected device or the buttons of the Bluetooth speaker

Auxiliary Line-in (AUX-IN):

For other compatible music player devices ,or MP3/MP4 players ,please use the supplied auxiliary audio line cable to connect from your external device's "LINE OUT" jack to the "AUX-IN" jack of this unit ,The press the "MODE "button to switch to the AUX-IN mode .

While using an external device ,all functions will be controlled by the external device except for the PLAY/PAUSE button

****The speaker can't waterproof when using AUX function and recharge battery as the cover is opening**

Pairing the speaker

1. Long Press power  to open the device, a tone will be heard and the LED indicator light will begin to flash BLUE quickly
 2. Keep your speaker and your Bluetooth enabled device within 3 feet of each other during the pairing process
 3. Open the Bluetooth settings menu on your mobile device ,Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices
 4. When your Bluetooth enabled device finds the speaker, ,select your pair code from the list of found devices
 5. Some Bluetooth enabled devices require a password to connect ,if one is required ,enter the password 0000,Select ok or yes to pair the speaker to your device
 6. After a successful pairing ,the LED Bluetooth indicator light will flash BLUE slowly
- NOTE:If you would like to connect the speaker to another device ,you must unpair the speaker from the currently paired device first ,On your device's Bluetooth settings ,select your pair code then select "unpair" or "forget device" The speaker will return to pairing

Speaker Specifications:

- Output power: 5W*2
- Speaker unit: 2.75inch *2
- Frequency response:100Hz-20KHz
- Signal-to-noise: ≥80dB
- Product Size: L282XH106XD75mm
- Battery capacity:2000mAh Li-polymer battery
- With Aux, Bluetooth
- Accessories: 3.5mm cable ,USB-Micro USB cable ,User manual

Warnings &Precautions

This speaker has an IP67 rating ,which means that it is completely dust-tight and protected against water ingress up to 3 feet(1 meter)deep .Do not submerge for longer than 30 minutes

Do NOT attempt to open the water-tight waterproof USB cover on the Waterproof speaker before drying the speaker thoroughly and completely

Do NOT open the Waterproof USB Cover while the device is in water or bvery humid places ,such as swimming pools or bathrooms

Do NOT expose this speaker to a constant stream of running water such as ocean waves

Damage ,shock ,and/or injury can occur if this warning is not heeded properly