ACONATIC

# คู่มือการใช้งาน

## พัดลมไอเย็น

## รุ่น: AN-ACC1320

คำแนะนำ

กรุณาศึกษาคู่มืออย่างละเอียด ก่อนทำการติดตั้งและใช้งานโทรทัศน์

เก็บคู่มือนี้ไว้ใช้อ้างอิง

# คู่มือการใช้งาน

AIR COOLER

รุ่น AN-ACC1320

อ่านคู่มือฉบับนี้อย่างละเอียดก่อนที่จะใช้และเก็บคู่มือนี้ไว้สำหรับการอ้างอิง






ข้อมูลจำเพาะ

- แรงดันไฟฟ้าที่กำหนด : 220V~
- ความถี่ไฟฟ้าที่กำหนด: 50 เฮิร์ต
- กำลังไฟฟ้าที่ใช้: 200 วัตต์
- ปริมาณความจุของถังใส่น้ำ: 40 ลิตร

**การติดตั้งพัดลมไอเย็น**

1. ถอดอุปกรณ์ต่างๆอย่างระมัดระวังเพื่อป้องกันไม่ให้ตัวเครื่องพลาสติกเสียหายด้วยกรรไกรหรือมีด
2. การติดตั้งล้อ: วาง 4 ล้อไปที่รูที่อยู่ใต้ฐานของพัดลมไอเย็น ใส่ล้อให้แน่นเข้ากับตัวพัดลมไอเย็นแล้วขันสกรู
3. วางตำแหน่งที่มั่นคงเพื่อให้ห่างจากแหล่งความร้อนที่และเปลวไฟ
4. เติมน้ำ: เปิดล็อคถังน้ำให้อยู่ในแนวราบดึงถังน้ำใส่เจลทำความเย็นและใส่น้ำสะอาดลงถัง ตรวจสอบให้แน่ใจว่าระดับน้ำในถังไม่เกินระดับ "MAX" ซึ่งอยู่ที่ด้านหลังของถัง
5. ดันที่ใส่ถังน้ำเข้าที่เติมและหมุนล็อคถังให้อยู่ในแนวตั้ง
6. เติมน้ำด้วยระบบเติมน้ำ (ดูภาพ)
7. สามารถใส่เจลทำความเย็นได้ที่ฝาด้านบนตัวเครื่อง



**แผงควบคุม**




1. เปิด / ปิด: กดปุ่ม "ON / OFF" บนแผงควบคุมหรือกดปุ่ม ON / OFF บนรีโมทคอนโทรลเพื่อเปิดเครื่อง เครื่องจะเริ่มต้นที่ความเร็วต่ำและลมปกติ หากต้องการเปลี่ยนกลับไปที่ตำแหน่งสแตนด์บายเพียงกดปุ่มเปิด / ปิดบนแผงควบคุมหรือกดปุ่มเปิด / ปิดบนรีโมทคอนโทรล
2. ความเร็ว: ความเร็วลมสามารถปรับระดับได้ 3 ระดับคือต่ำกลางสูง 0 --- stop, 1 --- ต่ำ, 2 --- กลาง, 3 --- สูง
3. สวิง: กดปุ่ม 'Swing' เพื่อเปลี่ยนทิศทางลม โอคอนสวิงจะปรากฏขึ้นบนหน้าจอเมื่อเปิดใช้งานฟังก์ชั่น กดปุ่มอีกครั้งเพื่อหยุดการสวิง ถ้าทิศทางลมในแนวตั้งสามารถปรับได้ด้วยตนเองโดยสามารถปรับได้ทั้ง ขึ้น/ลง
4. Cooler: เพื่อเปิดใช้งานฟังก์ชั่น ทำความเย็นให้กดปุ่ม 'Cool' เครื่องจะสูบน้ำจะนำน้ำออกจากถังและไหลลงบนแผ่นระบายความร้อน แผ่นระบายความร้อนดูดซับความร้อนของน้ำและอากาศที่ระเหยจะถูกเป่าออกด้วยใบพัดทำให้อุณหภูมิลดลง

**การใช้งานถังน้ำ**

ตรวจสอบระดับน้ำในถังบ่อยๆ ให้แน่ใจว่าระดับน้ำไม่ต่ำกว่าเครื่องหมาย 'MIN' ที่อยู่ในถังน้ำ การเปิดใช้งานฟังก์ชั่น "Cool" ด้วยปริมาณน้ำไม่เพียงพออาจทำให้เครื่องสูบน้ำทำงานผิดปกติและการรับประกันสินค้าของคุณจะเป็นโมฆะก่อนที่จะเติมน้ำ ให้ปิดเครื่องไปที่ตำแหน่ง 'ปิด' โดยกดสวิตช์ที่อยู่บนแผงด้านบนและถอดปลั๊กไฟออก

**การใช้เจลทำความเย็น**

เปิดฝาด้านบนและใส่เจลทำความเย็นเพื่อเพิ่มประสิทธิภาพการทำความเย็นของพัดลม คุณสามารถใช้เจลทำความเย็นที่มาพร้อมกับตัวเครื่องได้ ก่อนใช้ให้เก็บไว้ในช่องแช่แข็งในตู้เย็นสักสองสามชั่วโมง จากนั้นใส่ลงในส่วนของถังน้ำและเติมน้ำที่ระดับ 'MAX' การใช้เจลทำความเย็นจะทำให้อุณหภูมิลดลงซึ่งจะสร้างความเย็นได้ดีขึ้น



**ข้อควรระวังเพื่อความปลอดภัย**

1. ตรวจสอบให้แน่ใจว่าตัวเครื่องและสายไฟไม่เกิดความเสียหายก่อนใช้งาน ในกรณีที่เกิดความเสียหายโปรดปรึกษาผู้ให้บริการด้านเทคนิคที่ได้รับอนุญาตหรือติดต่อศูนย์บริการ
2. ห้ามนำถังน้ำออกก่อนที่จะถอดปลั๊กไฟ
3. ห้ามนำวัตถุหรือสิ่งแปลกปลอมเข้าสู่ช่องระบายอากาศเพราะอาจทำให้ผลิตภัณฑ์เกิดความเสียหายและอาจทำให้เกิดไฟฟ้าช็อต
4. ห้ามใช้งานเครื่องขณะปิดฝาครอบ เนื่องจากอาจทำให้เกิดความร้อนสูงเกินไปและเกิดความเสียหายกับมอเตอร์ได้
5. เมื่อทำความสะอาดหรือทำการเคลื่อนย้าย ต้องถอดปลั๊กออกจากแหล่งจ่ายไฟเมื่อไม่ใช้งาน
6. ห้ามใส่สารเคมีลงในถังน้ำ เนื่องจากทำให้เครื่องชำรุดและอาจเป็นอันตรายต่อผู้ใช้งาน
7. เด็กทารก ผู้สูงอายุและบุคคลที่มีภูมิคุ้มกันน้อยไม่ควรสัมผัสกับลมเป็นเวลานาน
8. เครื่องใช้ไฟฟ้านี้ควรใช้แรงดันไฟฟ้าและความถี่ที่กำหนดไว้ตามที่ระบุไว้ในฉลาก
9. ไม่ควรดึงปลั๊กไฟออกจากด้าเสียบไฟฟ้า หากมือของคุณเปียกน้ำ
10. ห้ามให้ผู้ที่มีความสามารถทางร่างกายและทางประสาทสัมผัสหรือขาดประสบการณ์และความรู้ใช้เว้นแต่จะได้รับการดูแลหรือคำแนะนำเกี่ยวกับการใช้เครื่องโดยผู้รับผิดชอบด้านความปลอดภัย
11. ไม่ควรให้เด็กใช้งานเครื่องตามลำพัง ควรอยู่ภายใต้การดูแลของผู้ปกครอง
12. ไม่ควรนำพัดลมไอเย็นไปใช้งานในบริเวณที่ตัวเครื่องเสี่ยงต่อการโดนน้ำ เพราะอาจทำให้เกิดไฟฟ้าลัดวงจรหรือไฟไหม้ได้
13. ไม่ควรถอดปลั๊กออกขณะพัดลมไอเย็นยังทำงานอยู่ และ ตรวจสอบให้แน่ใจว่าเสียบปลั๊กไว้แล้วก่อนเริ่มทำการใช้งาน
12. ไม่ควรนำพัดลมไอเย็นวางไว้ภายนอกอาคารที่มีแสงแดดเป็นระยะเวลานาน

**การทำความสะอาดและการบำรุงรักษา**

หลังจากการใช้งานเป็นระยะเวลานานอาจมีฝุ่นสะสมในแผ่นกรองฝุ่นหรือแผ่นทำความเย็น อาจส่งผลต่อการไหลเข้าของอากาศ ขอแนะนำให้ทำความสะอาดพัดลมไอเย็นอย่างสม่ำเสมอ และโปรดปฏิบัติตามขั้นตอนต่อไปนี้ เพื่อทำความสะอาดอุปกรณ์ ควรปิดเครื่องและถอดปลั๊กไฟออกก่อนทำความสะอาดและบำรุงรักษา



**1.แผ่นกรองฝุ่น**

หากต้องการนำแผ่นกรองฝุ่นออกให้ออดสกรูออกก่อน จากนั้นให้กดล็อคด้วยมือทั้งสองข้างและดึงออกใช้สารทำความสะอาดที่มีคุณสมบัติเป็นกลาง เช่น น้ำเปล่า, ผงซักฟอกและแปรงเพื่อทำความสะอาดฝุ่นและสิ่งสกปรกบนแผ่นกรอง หากต้องใส่แผ่นกรองให้วางส่วนล่างของตัวกรองไว้ก่อนจากนั้นดันส่วนบนจนกว่าจะล็อคแน่น

**2.แผ่นทำความเย็น**

หลังจากถอดแผ่นกรองฝุ่นแล้วคุณจะเห็นแผ่นทำความเย็น กดล็อคตรงกลางและค่อยๆดึงแผ่นออก ใช้แปรงที่สะอาดเพื่อขจัดฝุ่นละอองและสิ่งสกปรกออกจากแผ่นทำความเย็น จากนั้นล้างออกด้วยน้ำสะอาด และทิ้งไว้ให้แห้งในที่ที่มีอากาศถ่ายเท ห้ามใช้สารเคมีและสารอันตรายใด ๆ ที่เป็นอันตรายต่อแผ่นทำความเย็นในการทำความสะอาด

**3.ถังน้ำ**

หมุนตัวล็อคถังน้ำให้อยู่ในแนวนอนและดึงถังออก ใช้น้ำยาทำความสะอาดที่มีฤทธิ์อ่อนเพื่อทำความสะอาด ล้างออกด้วยน้ำสะอาดและล้างบริเวณโดยรอบถังน้ำ เมื่อล้างเสร็จดันถังน้ำเข้าเบาๆ หมุนตัวล็อคให้อยู่ในแนวตั้ง

**4.การทำความสะอาดตัวเครื่อง**

ทำความสะอาดตัวเครื่องของพัดลมไอเย็นโดยใช้ผ้าชุบน้ำหมาด ๆ มาเช็ดโดยรอบ ยกเว้นแผงควบคุม ไม่ควรใช้สารทำความสะอาดที่มีความเป็นกรดสูง

**ข้อควรระวัง:** ไม่ควรให้น้ำโดนแผงควบคุม ทำความสะอาดด้วยผ้านุ่มเป็นประจำ



# INSTRUCTION MANUAL

**AIR COOLER**

**AN-ACC1320**

READ THIS MANUAL THOROUGHLY BEFORE USING AND SAVE IT FOR FUTURE REFERENCE.






**Technical Specifications**

- Rated Voltage : 220V~
- Rated Frequency: 50Hz
- General Power: 200W
- Water Tank Capacity: 40L

**Assembly of the Air Cooler**

1.Remove the packaging carefully taking care not to damage the plastic body with the scissors or knife
2.Installation of Wheels: place 4 wheels to the holes located at the base of the air cooler. Insert the wheels tightly to the air cooler's body.
3.Set the unit on a stable and horizontal base,keeping it away from radiating heat sources and naked flame.
4. Filling Water: Turn the water tank lock to horizontal position, taking out the water tank, put in the ice boxes and add clean tap water to the tank. Be sure that water level in the tank does not exceed the level "MAX" which is located at the back of the tank.
5.Push the water tank to its housing and turn the tank lock to the vertical position.
6.Add water by Water system filler(you can see with photo)
7.Ice box in top cover.



**Operating the Air Cooler**




1.**ON/OFF**: Press the "ON/OFF" button on the control panel or press the ON/OFF button on the remote control to turn the unit on. The unit will start at low speed and normal wind. To switch back to the standby position, simply press the ON/OFF button on control panel or press the ON/OFF button on the remote control.
2. **Speed**: Wind speed can be adjusted to 3 levels as low---mid—high, 0---stop,1---Low,2---Mid,3---High.
3. **Swing:** Press 'Swing' button to change the wind direction. The swing icon will appear on the screen when the function is activated. Press the button again to stop the oscillation. The vertical direction of air flow can be adjusted manually by directing the outlet louvers up and down.
4. **Cooler:** To activate the air cooler function, please press the 'Cool' button. Water pump will take the water from the tank and pour it onto the cooling pad. Cooling pad absorbs the heat of the water and the evaporated air is blown out by the help of fan. The cool breeze blown by the cooler drops the temperature and creates a relaxing cooling effect.

**Operating the Water Tank**

Check the level of water in the tank frequently. Be sure that water level is not below the 'MIN' marking which is located on the water tank. Activating the 'Cool' function with insufficient amount of water may cause malfunction of the water pump and the warranty of your product will be void.

Before refilling water, turn your unit to 'Off' position by pressing the switch located on the back panel and unplug the power cord.

**Using the Ice Boxes**

Open the top lid and put in the ice box.
In order to increase the cooling effect of your fan, you can use ice boxes which are



supplied with the unit. Before using, place them in the freezing compartment of your refrigerator for a few hours. Then place them into the large section of the tank and add water to the 'MAX' level. Using the ice boxes will drop the temperature of the air flow which will create more effective cooling effect.

**Safety Precautions**

1. Make sure this appliance and the power cord is not damage before operating. In case of damage, please consult to your authorized technical service.
2. Do not take out water tank before unplugging the power cord plug.
3. Do not insert or allow objects to enter any ventilation or exhaust opening as this may damage the product and could cause an electrical shock or fire.
4. Do not operate your unit with a cover on it as this may result overheating and motor damage.
5. The plug must be removed from the electrical outlet when not operating and before moving, installing, uninstalling and cleaning.
6. Do not add any chemical, metal ingredients into the water tank. These materials are dangerous and any cause problems.
7. Baby, old people and valetudinarianism should not be exposed directly to the fan wind for a long time.
8. This appliance should be used under the rated voltage and frequency as indicated in rating label.
9. If you hands are wet, do not pull out the plug from the electrical outlet.
10. This appliance is not intended for use by persons(including children)with reduce physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
11. Children should be supervised to ensure that they do not play with the appliance.
12. Do not use your fan in or around water which may cause electric shock and risk of fire.
13. Do not pull the plug while the power is on. Always ensure that the plug is fully inserted into the electrical outlet before operating.
14. Do not leave your unit under direct sunlight for a long time

**Cleaning and Maintenance**

After operation for long time, the dust cumulated in the dust filter or cooling pad may influence the inflow of air. Therefore it is recommended to clean your fan regularly. Please follow the steps below to clean your device.
Turn off the unit and unplug the power cord before cleaning and maintenance.

**1. Dust Filter**
To remove the dust filter, first remove the screw, then simply press the locks with both



hands and pull it out. Use neutral cleaning agent and brush to clean the dust and dirts on the filter. To attach the clean filter, place the bottom of the filter first and then push upper part until it is locked tightly.
**2. Cooling Pad**
After removing the dust filter you can see the cooling pad. Press the lock in the middle and gently pull out the pad. Use a clean or soft brush to remove dust and dirt from the pad. Rinse with water if needed and leave it to dry in open air. Never use any chemical cleaning solution that can harm pad.
**3. Water Tank**
Turn the water tank lock to horizontal position and pull the tank. Use soft cleaning agents for cleaning. Wash with water and rinse the place it to its housing by pushing gently. Turn the lock to vertical position.
**4. Exterior Cleaning**
Clean the exterior case of the fan with a soft damp cloth except control panel. Never use hard cleaning agent that can harm the case. Make sure the unit is dry before operating it.

**Caution:** Never let water contact with the control panel. Always clean it with a soft dry cloth.



ACONATIC

บริษัท ไฮฟ โอเรียนท์ ไทย จำกัด (มหาชน)
HIFI ORIENT THAI PUBLIC COMPANY LIMITED
83/163 -182 ซอยรามคำแหง17(ศรีบำเพ็ญ2) Tel: 0-2504-5291 , 0-2504-6055
เขตวังทองหลือง กทมเขตนี้ Cust Line: 02-591-9444 , 02-589-5115
กรุงเทพมหานคร 10210

หมายเหตุ : บริษัทขอสงวนสิทธิ์ในการเปลี่ยนแปลงรายการของสินค้าหรือและราคาสินค้าโดยมิต้องแจ้งให้ทราบล่วงหน้า

145x210mm(20181219/YS1812191132)